3D BRACELET JIG TEMPLATE

Swoosh Bangle

Materials: 24 inches of 14Ga or 16Ga Artistic Wire - Set 16 pins into the 3D Bracelet Jig as shown following the guide. Using the Wire Gauge of your choice and choose if you will make Option 1 (wire only) or Option 2 Wire With Beads.

Option 1: Working from the spool of wire (either 14Ga or 16Ga) wrap the wire around the pegs until you reach the other side of the Jig. To remove the design from the Jig, remove the pegs. Finish by using the appropriate Artistic Wire Large Wire Crimp Tube to connect the two ends.



Option 2: Working from the spool of wire (14Ga or 16Ga) add beads to the wire before you begin. Deposit the beads where you like as you go. Place each bead as you pass the pegs where you want them to be positioned. Continue until you reach the other side of the Jig. To remove the design from the Jig, remove the pegs. Finish by using the appropriate Artistic Wire Large Wire Crimp Tube to connect the two ends.



2 O 3 O 4 5 O O 6 O O O O 7 O 8 O 9 O 10 O O 11 O O 12 O 13 O 14 15 O 16 O O 17 O O 18 O O 19 O 20 O O 21 22 0 23 24 O 25 26 O 27 28 29 30 31 O O 32 O 33 O O 34 O O 35 O O 36 O O 37 O O 38 39 O 40 41 O 42 43 O 0 0 44

BCDEFG

0

1